



Appendix user manual humimeter FS4.2

General Information:

The general handling can be taken out of the provided user manual of the humimeter FS4, just as the technical data. Furthermore you should use the user manual "costumer calibration for BM2 and FS4" if you want to create your own calibration curve.

Calibration curve:

There are free calibration curves. By the use of these calibrations curves you can deposit your own product in the device (costumer calibration for BM2 and FS4).

Cleaning & Servicing:

It is recommended to clean the measuring chamber in spaced intervals. This should be done under no circumstances with water. You should use compressed-air to blow out the measuring chamber. You could also use a brush or a cloth to remove residues. Do not use any aggressive cleaning agents!!

If the device is for a longer period not in use, then the batteries should be taken out of the device.

Contact:

If there are any questions, please do not hesitate to contact us.



1295 Morningside Ave., Unit 16-18
Scarborough, ON M1B 4Z4 Canada
Phone: 416-261-4865 Fax: 416-261-7879
www.scigiene.com